INSTALLATION GUIDE - WM2335

- 1. Attach the bridges to holder with the tube and longer screws.
- 2. Put each piece of glass shades into the channel of bridges and fix them with the square covers and shorter screws.
- 3. Drill the mounting bracket into the ceiling with screws and even anchors (these come with the light).
- 4. Use the wire connector to connect the wires of the light to the supply wires according to labels on the wires.
- 5. Align the canopy holes with the mounting bracket and secure the canopy with screws.



