



Warning:
This product must be installed by personnel who are familiar with its structure and related hazards, in accordance with the installation specifications. This product is suitable for indoor installation.




Product style diagram


Steps of installation



1 Tighten the threaded rod onto the base, then install the bent pipe connecting rod onto the threaded rod.



2 Next, insert the light source into the lamp body rod, then screw the light source tube cover onto the lamp body rod, then screw the light source cover cap onto the light source tube cover, then screw the gear onto the light source cover, then insert the silicone gasket, then put the lamp cover in, and finally lock the lamp cover nut.



Tighten the threaded rod (**H**) onto the base (**I**), then install the bent pipe connecting rod (**G**) onto the threaded rod (**H**), then insert the light source (**F**) into the lamp body rod (**B**), then screw the light source tube cover (**E**) onto the lamp body rod (**B**), then screw the light source cover cap (**D**) onto the light source tube cover (**E**), then tighten the gear onto the light source cover (**E**), then insert the silicone gasket (**C**), and finally place the lamp cover (**B**) in, and then lock the lamp cover nut (**A**)