



Warning:

This product must be installed by personnel who are familiar with its structure and related hazards, in accordance with the installation specifications. This product is suitable for indoor installation.




Product style diagram


Steps of installation




Use the terminal block to connect the wires of the mounting plate to the wires on the top of the pillar.



Remove the mounting plate, and fix it on the top of the pillar, covering the wires.



Align the holes of the lamp body with the holes of the mounting plate, and tighten the screws.



First, use the terminal block (C) to connect the wires of the mounting plate (B) to the wires on the top of the pillar. Then, remove the mounting plate (B), and fix it on the top of the pillar, covering the wires. Next, align the holes of the lamp body (A) with the holes of the mounting plate (B), and tighten the screws.

Directions For Use

Intelligent/Remote control

