

Installation Instructions


WOMO®

Model number: WM2863


Warning:

This product must be installed by personnel who are familiar with its structure and related hazards, in accordance with the installation specifications. This product is suitable for indoor installation.


Steps of installation




Install the mounting plate to the ceiling.




Align the hole of the top cover with the hole of the mounting plate and tighten the screws.




Product style diagram



Use terminal to connect the power drive line and the ceiling line



Align the threaded bush of the light pole with the holes in the round tube and tighten the nut/lock, align the threaded rod of the lamp body with the nut in the round tube, and tighten the lamp body.



First, align the threaded bush of the light pole (A) with the holes in the round tube (B) and tighten the nut/lock, align the threaded rod of the lamp body (C) with the nut in the round tube (B), and tighten the lamp body (C). Then, hook the chain (D) to the lamp body (B) and the top cover (G), then pass the wire through the chain (D) and the top cover (G), and then fix the wire to the positive and negative poles of the power drive line, install the mounting plate (A) to the ceiling. Then, use terminal (F) to connect the power drive line and the ceiling line/lock, align the hole of the top cover (G) with the hole of the mounting plate (A) and tighten the screws.