


### Warning:


This product must be installed by personnel who are familiar with its structure and related hazards, in accordance with the installation specifications. This product is suitable for indoor installation.



Product style diagram


### Steps of installation

1




Lock this fitting to the lamp arm and lock the screw.

2




Pass the reserved line through the adjustment rod of the lamp arm, and then install it onto the top cover.

3




First, fix the expansion screws onto the ceiling, and then lock the mounting plate onto the screws.

4



Connect the reserved wires on the lamp arm and the ceiling to the terminal blocks, then fix the lamp body to the ceiling, and tighten the screws at the bottom of the lamp cover.




First, pass the reserved wire through the accessory and attach it to the lamp arm (D). Then, install the lamp arm (D) onto the top cover (C). Next, connect the reserved wire to the power driver. Then, fix the mounting plate (A) to the ceiling.

After that, connect the wires on the ceiling and the power supply wire to the terminal (B). Align the holes at the bottom of the top cover (C) with the holes on the mounting plate (A), and then tighten the screws at the bottom.


### Warning:

This product must be installed by personnel who are familiar with its structure and related hazards, in accordance with the installation specifications. This product is suitable for indoor installation.




Product style diagram


### Steps of installation




Lock this fitting to the lamp arm and lock the screw.




Pass the reserved line through the adjustment rod of the lamp arm, and then install it onto the top cover.



First, fix the expansion screws onto the ceiling, and then lock the mounting plate onto the screws.




Connect the reserved wires on the lamp arm and the ceiling to the terminal blocks, then fix the lamp body to the ceiling, and tighten the screws at the bottom of the lamp cover.



First, pass the reserved wire through the accessory and attach it to the lamp arm (D). Then, install the lamp arm (D) onto the top cover (C). Next, connect the reserved wire to the power driver. Then, fix the mounting plate (A) to the ceiling. After that, connect the wires on the ceiling and the power supply wire to the terminal (B). Align the holes at the bottom of the top cover (C) with the holes on the mounting plate (A), and then tighten the screws at the bottom.


### Warning:

This product must be installed by personnel who are familiar with its structure and related hazards, in accordance with the installation specifications. This product is suitable for indoor installation.




Product style diagram


### Steps of installation




Lock this fitting to the lamp arm and lock the screw.




Pass the reserved line through the adjustment rod of the lamp arm, and then install it onto the top cover.



First, fix the expansion screws onto the ceiling, and then lock the mounting plate onto the screws.



Connect the reserved wires on the lamp arm and the ceiling to the terminal blocks, then fix the lamp body to the ceiling, and tighten the screws at the bottom of the lamp cover.



First, pass the reserved wire through the accessory and attach it to the lamp arm (D). Then, install the lamp arm (D) onto the top cover (C). Next, connect the reserved wire to the power driver. Then, fix the mounting plate (A) to the ceiling. After that, connect the wires on the ceiling and the power supply wire to the terminal (B). Align the holes at the bottom of the top cover (C) with the holes on the mounting plate (A), and then tighten the screws at the bottom.